



CAD-Planungsdarstellung / CAD files: Combilift 542-2,6

Dateiname / File name:
542-26-200-220_comfort

Wöhr - Combilift 542-2,6 (Komforttyp)
Wöhr - Combilift 542-2,6 (Comfort type)




Dateiname / File name:
542-26-200-220_comfort-planning




Dateiname / File name:
542-26-230-235_premium

Wöhr - Combilift 542-2,6 (Premiumtyp)
Wöhr - Combilift 542-2,6 (Premium type)




Dateiname / File name:
542-26-230-235_premium-planning



CAD-Planungsdarstellung / CAD files: Combilift 542-2,6


Dateiname / File name:
DS-542_250_first

Combilift 542
Anfangsraster / First grid
Plattformbreite 250 / Platform width 250




Dateiname / File name:
DS-542_250_middle

Combilift 542
Folgeraster / Middle grid
Plattformbreite 250 / Platform width 250




Dateiname / File name:
DS-542_250_end

Combilift 542
Endraster / End grid
Plattformbreite 250 / Platform width 250




Dateiname / File name:
DS-542_260_first

Combilift 542
Anfangsraster / First grid
Plattformbreite 260 / Platform width 260




Dateiname / File name:
DS-542_260_middle

Combilift 542
Folgeraster / Middle grid
Plattformbreite 260 / Platform width 260




Dateiname / File name:
DS-542_260_end

Combilift 542
Endraster / End grid
Plattformbreite 260 / Platform width 260




Dateiname / File name:
DS-542_270_first

Combilift 542
Anfangsraster / First grid
Plattformbreite 270 / Platform width 270



Dateiname / File name:
DS-542_270_middle

Combilift 542
Folgeraster / Middle grid
Plattformbreite 270 / Platform width 270



Dateiname / File name:
DS-542_270_end

Combilift 542
Endraster / End grid
Plattformbreite 270 / Platform width 270

